

# How to repair external render

## using Blue Circle Cement

### Materials and Tools

- Blue Circle Extra Rapid Cement
- Sharp sand
- Water
- Trowel
- Mixing board
- Bucket
- Stiff brush
- Sponge
- Plastic sheeting
- Safety gear

### Step by step guide

- 1. Prepare the Area** - Clean the area by removing loose render and dust using a stiff brush. Dampen the area with water.



- 2. Mix the Mortar** - Mix a ratio of one part Blue Circle Extra Rapid Cement and five parts sharp sand with water to achieve a stiff consistency.



- 3. Make the Repair** - Use the trowel to place the mortar well into the repair area to fill the void and match the surrounding surface.



Clean your tools promptly after finishing to prevent any material from hardening on them.

- 4. Curing** - Allow the repaired render to dry completely for at least 7 days before painting.

